

## WDP Setup Menu

# START SETUP

Scan **START SETUP** to enter setup mode



## WDP Setup Menu

# RESET

**Warning:** Scanning this bar code after scanning **START SETUP** will reset the reader back to all of the default parameter settings.



## WDP Setup Menu

# 2 of 5 Length

Scan 2 digit length (default is 06)



## WDP Setup Menu

# MSI / Plessey

- |                                      |                            |
|--------------------------------------|----------------------------|
| *0) Disable MSI                      | 5) Transmit 1 check digit  |
| 1) Enable MSI 1 Mod 10 check digit   | 6) Transmit 2 check digits |
| 2) Enable MSI 2 Mod 10 check digits  | 7) Enable Plessey          |
| 3) Enable MSI Mod 11/10 check digits | 8) Enable Labelcode 5      |
| *4) Transmit no check digit          | 9) Enable Labelcode 4      |



## WDP Setup Menu

# Postamble

Scan up to 15 characters from the **Full ASCII Menu**. Scan **SET** when completed.



## WDP Setup Menu

# CLEAR

Clears Preamble & Postamble and resets current individual parameter back to default settings.



## WDP Setup Menu

# UPC / EAN

- |                                     |  |
|-------------------------------------|--|
| *0) Enable UPC/EAN                  | 8) Transmit UPC-E NSC & EAN-8 Flag Ch          |
| 1) Disable UPC/EAN                  | 9) Don't transmit UPC-E NSC & EAN-8 Flag Ch    |
| 2) Enable Supplements               | A) Transmit UPC-E & EAN-8 Check digit          |
| *3) Disable Supplements             | * B) Don't transmit UPC-E & EAN-8 Check digit  |
| *4) Transmit UPC-A NSC              | * C) UPC-E Compressed transmission             |
| 5) Don't transmit UPC-A NSC         | D) UPC-E Expanded transmission                 |
| *6) Transmit UPC-A Check Digit      | * E) EAN-8 observes 9 & A above                |
| 7) Don't transmit UPC-A Check Digit | F) EAN-8 is forced to transmit 8 digits always |



## WDP Setup Menu

# Codabar

- |                        |                                    |
|------------------------|------------------------------------|
| 0) Enable Codabar      | *3) Disable CLSI Codabar           |
| *1) Disable Codabar    | *4) Suppress start/stop characters |
| 2) Enable CLSI Codabar | 5) Enable start/stop characters    |



## WDP Setup Menu

# Data Transmission Timing

- \*0) None
- 1) Short
- 2) Short Medium
- 3) Medium
- 4) Long

*This adjusts for differences in BIOS and clock speeds*



## WDP Setup Menu

# Beep Tone

- |            |                 |
|------------|-----------------|
| 0) Lowest  | 3) High         |
| 1) Low     | 4) Highest      |
| *2) Medium | 5) No Beep Tone |



## WDP Setup Menu

# SET



## WDP Setup Menu

# END SETUP

When all changes have been made, scan END SETUP



## WDP Setup Menu

# 2 of 5 Code

- 0) Enable 1 2 of 5
- \* 1) **Disable 1 2 of 5**
- 2) Enable check digit
- \* 3) **Disable check digit**
- 4) Transmit check digit
- \* 5) **Don't transmit check digit**
- 6) Enable 2 of 5
- \* 7) **Disable 2 of 5**



## WDP Setup Menu

# Code 3 of 9

- \* 0) **Enable Code 39**
- 1) Disable Code 39
- \* 2) **Enable Full ASCII Code 39**
- 3) Disable Full ASCII Code 39
- \* 4) **Enable Accumulate Mode**
- 5) Disable Accumulate Mode
- 6) Transmit Start/Stop characters
- 7) **Don't transmit Start/Stop characters**
- 8) Enable Mod 43 Check Character
- \* 9) **Disable Mod 43 Check Character**
- A) Transmit Mod 43 Check Character
- \* B) **Don't transmit Mod 43 Check Character**
- C) Caps Lock ON
- \* D) **Caps Lock OFF**



## WDP Setup Menu

# RSS-14

- \* 0) **Disable RSS-14**
- 1) Standard 14 digits
- \* 3) 14 + identifiers
- \* 4) 14 + UCC-128 emulation



## WDP Setup Menu

# Code 128

- 0) Disable 128
- \* 1) **Enable 128**
- 2) Disable UCC/EAN-128
- 3) **Enable UCC/EAN-128**



## WDP Setup Menu

# Preamble

Scan up to 15 characters from the Full ASCII Menu.  
Scan SET when completed.



## WDP Setup Menu

# Computer Interface

- \* 1) **PC Keyboard and USB Wedge Saver**
- 3) PC Learned Timing



## WDP Setup Menu

# Magstripe

- \* 0) **None**
- 1) Track 1
- 2) Track 2
- 3) Track 3
- 4) Tracks 1 & 2, 2 & 3
- \* E) **Caps Lock OFF**
- F) Caps Lock ON



## WDP Setup Menu

# Characters

Scan up to 8 sets of hex characters to reassign and delete characters in the bar code output.  
Scan SET when completed.



WDP Setup Menu

# Terminator Character

- \*0) Enter
- 1) None
- 2) Tab



WDP Setup Menu

3



WDP Setup Menu

A



WDP Setup Menu

# Keyboard Country

- |                  |                 |                |
|------------------|-----------------|----------------|
| *00) USA         | 05) Danish      | 10) Portuguese |
| 01) French       | 06) Dutch       | 11) Spanish    |
| 02) German       | 07) Italian     | 12) Swedish    |
| 03) Belgian      | 08) Latin Amer. | 13) Swiss      |
| 04) Fr. Canadian | 09) Norwegian   | 14) U.K.       |



WDP Setup Menu

7



WDP Setup Menu

E



8



F

WDP Setup Menu

1



WDP Setup Menu

9



WDP Setup Menu

Code 93

0) Enable Code 93  
\* 1) Disable Code 93

2) Enable Full ASCII Code 93  
\* 3) Disable Full ASCII Code 93



2



WDP Setup Menu

5



WDP Setup Menu

C



9



D